


Table of Contents

The Pumping Principle.....	3
Location.....	3
Proper Installation.....	3
Filter Protection.....	4
Startup.....	4
Disassembly of Seal.....	5
Disassembly of Pump.....	5
Inspection.....	6
Reassembly of Pump.....	6
Pump Selection.....	6
1008 & 1010 Series Drawing.....	7
1008 Parts List.....	7
1010 Parts List.....	8
Field Checklist.....	8
Material Returns.....	9

The Pumping Principle

Tuthill internal-gear principle is based upon the use of a rotor, idler gear and crescent shaped partition that is cast integrally with the cover. (See accompanying figure). Thus, only two moving parts comprise this efficient pumping element. Power is applied to the rotor and transmitted to the idler gear with which it meshes. The space between the outside diameter of the idler and the inside diameter of the rotor is sealed by the crescent. When the pump is started, there is an increase in volume as the teeth come out of mesh. This creates a partial vacuum, drawing the liquid into the pump through the suction port. The liquid fills the space between the teeth of the idler and rotor and is carried past the crescent partition to the pressure side of the pump. When the teeth mesh on the pressure side, the liquid is forced from the spaces and out through the discharge port.



WARNING

Failure to follow these instructions could result in serious bodily injury or death. These pumps should not be used for handling plain water, corrosive/abrasive liquids, or liquids not possessing adequate lubricity. Do not attempt to work on any Tuthill pump installation before completing the steps below. Disconnect the drive so that it cannot be started while work is being performed. Review the Material Safety Data Sheet (MSDS) applicable to the liquid being pumped to determine its characteristics and the precautions necessary to ensure safe handling. Vent all pressure within the pump through the suction or discharge lines. All Tuthill pumps contain residual ISO 32 lube oil from the factory production test. Determine if this is compatible with the fluid you are pumping. If the fluid is incompatible please consult factory directly.

Location

The pump should be located as close to the source of supply as conditions will permit, below the level of the liquid in the reservoir, if possible. Pumps should be located in a dry and clean place, with space to work around them. When necessary to locate pumps in pits, provisions should be made to safeguard against floods. Care must be taken to properly support the suction and discharge piping so that no strain can be put on the pump from either its weight or expansion. Piping strains are very often the cause of misalignment, hot bearing, worn couplings and vibrations.

Proper Installation

A large percentage of unsatisfactory pump installations is caused by failure to observe the natural laws limiting the suction lifts on volatile materials. At temps. of approximately 70°F or lower, kerosene and light fuel oils may be pumped at nearly full volumetric efficiency when combined vertical lift and friction in the suction line do not cause a vacuum to exceed 10 inches of mercury at the suction port of the pump. Ten inches vacuum on kerosene oil is equal to approximately fourteen feet of vertical lift without pipe friction. This varies with the temperature and various oils, but if, in laying out the suction line, the maximum vacuum is kept at this figure or lower, good results may be expected. If this vacuum is exceeded, it is almost certain to result in cavitation, loss of volume and a noisy installation. When

pipelines are installed, an inverted “U” bend should be incorporated in the suction line close to the pump to trap liquid in the pump for priming. The suction line must be kept free from air leaks and air pockets. When handling liquids of high viscosity, such as asphalt, heavy gear lubricants, linseed oil, Bunker “C” fuel oil, molasses, etc., the speed of the pumps and the running clearances are important. Consult Tuthill UK, whenever unusual conditions of speed, pressure, vacuum or viscosity are encountered.

Before initial start of the pump, it is recommended that some of the liquid to be pumped be introduced into the pump ports to insure wetting of the rotation elements. Check alignment and rotation of the driver to see that pump will rotate in the designated proper direction of rotation.

Filter Protection

Piping or tubing should be cleaned out thoroughly to remove chips and pipe scale before connecting the piping to the pump.

Neglect of this precaution may result in damage to the pump when it is put in operation. The suction piping should be as short and direct as possible. Grit, pipe chips, or other foreign substance that is allowed to pass through the pump, will almost surely injure and possibly ruin it. Always remember the following in the selection and position of a filter.

- A filter should be installed to protect the pump whenever conditions permit
- When uncertain of pressure drop through the filter, obtain this data from manufacturer, giving pump capacity and type of liquid to be handled
- Install filter according to arrows or notation designating flow
- Have filter accessible for servicing
- Use duplex type where shutdown during servicing is not permitted
- Provide a vacuum gauge in the suction line for determining when the filter requires cleaning
- The greater the free opening, the less attention the filter will require

WARNING

All Tuthill pumps contain resigal ISO 32 lube oil from the factory production test. Determine if this is compatible with the fluid you are pumping. If the fluid is incompatible please consult factory directly. If the pump is to operate at elevated temperatures, it should be brought up to operating temperature gradually. Rapid or sudden introduction of liquid at an elevated temperature into the cold liquid chamber of the pump could cause damage to the seal or other internal parts. Do not run the pump dry. This could cause severe damage to the seal, bushings, and/or metal parts. Temperatures must not exceed 200°C without prior consent

Startup

Prior to starting the pump double check the following.

- Pressure and vacuum gauges should be installed as close as possible to the pump
- Rotate pump shaft to ensure it turns freely without binding
- Recheck alignment and ensure all guards are in place
- Make sure piping is independently supported and no strain is being transmitted to the pump
- Make sure the safety relief valve is installed correctly
- Check pump rotation
- Open suction and discharge gate valves
- Check for any leaks once gate valves are open

CAUTION

The pump should not be run dry. If after approximately 60 seconds there is no discharge of liquid, stop the pump and investigate the possible cause. Failure to comply with this could cause severe damage to internal seals, bushings and/or metal parts.

WARNING

Failure to follow these instructions could result in serious bodily injury or death. Do not attempt to work on any Tuthill pump installation before completing the steps below. Disconnect the drive so that it cannot be started while work is being performed. Review the Material Safety Data Sheet (MSDS) applicable to the liquid being pumped to determine its characteristics and the precautions necessary to ensure safe handling. Vent all pressure within the pump through the suction or discharge lines. All Tuthill pumps contain residual ISO 32 lube oil from the factory production test. Determine if this is compatible with the fluid you are pumping. If the fluid is incompatible please consult factory directly.

Disassembly of Seal

The seal assembly of the pump may be changed without the disassembly of the rest of the pump.

1. Remove all burrs on the shaft end and around the keyway area.
2. Hold the pump shaft upward in a vices so that the jaws grip across the two ports. Take care not to over tighten as this will distort the body. Unscrew the seal housing using a "C" spanner (Tuthill part no. 0L509) and remove seal plug and bearing.
3. Remove the seal assembly from the shaft by gently pressing down on the carbon to break the seal between the o-ring and the shaft and then pull upwards.
4. If it is necessary to strip the pump down completely then the 3/16th ball bearing will need to be removed from the shaft as well, once this is done remove the spring retaining plate. If the pump is not to be fully stripped down the ball bearing and retaining plate can be left in place.
5. The seal parts can now be inspected and replaced as necessary.
6. Inspect rotor, if badly scored in seal or bearing area, rotor should be replaced. Also check seal faces for the same scoring. Remove 0-rings and check for deformation, again replace if there is any doubt.
7. Be sure to clean all the parts thoroughly.
8. Turn pump upside down in the vice and place the spring plate over the shaft, making sure this is fully located onto the shoulder at the bottom of the shaft.
9. Take the 3/16th ball bearing and secure in the pre-drilled hole (retain using grease) .Take the carbon carrier and fit the o-ring, carbon and spring, lubricate with oil.
10. Using the keyway as a guide push the seal down the shaft engaging the ball bearing in the machined recess in the carbon carrier. When this is complete check that the seal moves freely up and down the shaft under spring pressure. Take the housing plug and fit the o-ring to the mechanical seal landing plate, lubricate and push fully home.
11. Fit the external o-ring to the housing and screw the housing into the pump bod making sure that the carbon carrier is still located over the bearing. Make sure pump still rotated freely when turned by hand.

Disassembly of Pump

1. Remove all burrs on the shaft end and around the keyway area.
2. Hold the pump, shaft upwards, in a vice. So that the jaws grip across the two ports, taking care not to over tighten as this will distort the body, unscrew the seal housing using a (C) spanner (Tuthill part no. 0L509) and remove seal plug and bearing.
3. Remove seal assembly from shaft- Gently press down the carbon to break the seal between the o-ring and shaft then pull upwards.
4. If it is necessary to strip the pump down completely then the 3/16th ball bearing will need to be removed from the shaft as well, once this is done remove the spring retaining plate.
5. Turn pump cover face upwards and secure in a vice.
6. Make a mark between cover and body and then undo the 6 bolts retaining the cover .
7. Remove the cover, taking care not to lose the cover o-ring, if one is present, and wipe off excess oil. Making sure there is sufficient clearance underneath the pump, (to prevent damage to the rotor vanes) press the rotor out through the body.

8. The individual parts must now be inspected for damage. The keyway in the end of the rotor must be in good condition and there must not be any deep scratches or grooves on the following surfaces.
 - The ID surface of the housing and OD of the rotor
 - The end face of the rotor and OD of the idler
 - Both faces of the idler
 - The inside surfaces of the cover including surfaces on the crescent
 - Areas on the shaft of the rotor were the seal seats

Inspection

Check cover, housing, rotor and idler for wear, chipped or broken teeth. Drop off in capacity is generally caused by the abrasive action of foreign materials in the oil, resulting in end play of the rotor. Check for side movement in the rotor assembly, as this indicates potential bearing failure.

Reassembly of Pump

1. De-burr all parts, then clean all parts thoroughly.
2. Install rotor assembly through pump body and push into place. Secure pump in a vice.
3. Add the cover o-ring and check that the gasket is not overlapping the o-ring groove (retain using oil).
4. Fit cover to the body using 6 off bolts and tighten down securely. Check pump shaft rotates freely when turned by hand.
5. Take the valve body, put one of the adjuster shims in the retaining sleeve and then place the spring assembly inside the sleeve.
6. Take the valve assembly and fit into pump, while the pump is on test you will have to adjust the pressure setting by adding or removing the adjusting shims.
7. Turn pump upside down in the vice and place the spring plate over the shaft, making sure this is fully located onto the shoulder at the bottom of the shaft.
8. Take the 3/16th ball bearing and secure in the pre-drilled hole (retain using grease) .Take the carbon carrier and fit the o-ring, carbon and spring, lubricate with oil.
9. Using the keyway as a guide push the seal down the shaft engaging the ball bearing in the machined recess in the carbon carrier. When this is complete check that the seal moves freely up and down the shaft under spring pressure.
10. Take the housing plug and fit the o-ring to the mechanical seal landing plate, lubricate and push fully home.
11. Fit the external o-ring to the housing and screw the housing into the pump body making sure that the carbon carrier is still located over the bearing. Make sure pump still rotates freely when turned by hand.

Pump Selection

The above pumps are only suitable for liquids having self-lubricating properties. The table below shows the capacity and suggested driving motor size for different speeds and pressures. These figures are based upon pumping a liquid of about 200 S.S.U. viscosity, and with a 10-inch vacuum. While Tuthill pumps will develop as high as 27 inches of vacuum, it is sound engineering to reduce the vacuum to a minimum. The speed of the pump must be reduced when handling liquids of high viscosity and the size on lines increased to prevent cavitation, loss of capacity and high power requirements.


CAUTION

Remember that the pipeline friction increases at a rapid rate with increase in viscosity. For a given pump and motor, larger pipelines are necessary to maintain the same pump pressure when changing from a thin liquid to a thick liquid. Viscous liquid pumping installations are notoriously under powered, due to lack of knowledge in computing pipeline friction. Handling of viscous liquids is a special hydraulic engineering problem, which the Engineering Department of Tuthill is well equipped to solve for you.

Consult Tuthill for selecting the proper pump, size of motor, and pipeline size for your job with the following information.

- Capacity required with max/min liquid temperatures when entering the pump
- The viscosity at the minimum temperature
- Total length of suction pipe and discharge pipe
- Suction lift and height to which the pump must force the liquid

1008 & 1010 Series Drawing



1008 Parts List

Item	Description	Quantity	Drawing Number	Part Number	Material	Size	Flange	O'Ring
1	Cover	1		1LF 35	Cast Iron	1/2	AFS-80-ST	BS 210
2	Gasket	As Req'd		0F 34	Melonex	3/4	AFS-80-ST	BS 210
3	Idler Pin	1		1L 31	Steel			
4	Idler Gear	1		1M5-8350	Steel/Carbon			
5	Body	1	1008		Cast Iron			
6	Rotor	1		A21165UK	EN1A			
7	Seal Assy	1		Various				
8	O'Ring	1		BSS222	Neoprene			
9	Housing Plug	1	A1188UK		Steel			
10	Bearing	1		6001ZZ	Various			
11	Bearing	1		6002	Various			
12	O'Ring	1		N/A	Neoprene			
13	Flange	1		As Req'd				
14	O'Ring	1		As Req'd				
15	Relief Valve	1	A1171UK	0LWW56XUK9219	Steel			
16	O'Ring	1		BS113	Neoprene			
17	O'Ring	1		As Req'd				
18	Flange	1		As Req'd				

1010 Parts List

Item	Description	Quantity	Drawing Number	Part Number	Material	Size	Flange	O'Ring
1	Cover	1	A1121UK	2L35XUK9219	Cast Iron	1/2	AFS-80-ST	BS 210
2	Gasket	As Req'd		2RFDXUK9219	Melonex	3/4	AFS-100-ST	BS 225
3	Idler Pin	1	9543A	2L 31	Steel			
4	Idler Gear	1	16103-B	2L5-8350	Steel/Carbon			
5	Body	1	1010		Cast Iron			
6	Rotor	1	A21100UK	A21100UK	EN1A			
7	Seal Assy	1		Various				
8	O'Ring	1		BS 222	Neoprene			
9	Housing Plug	1	A1188UK		Steel			
10	Bearing	1		6001ZZ	Various			
11	Bearing	1		6002	Various			
12	O'Ring	1		BS 132	Neoprene			
13	Flange	1		As Req'd				
14	O'Ring	1		As Req'd				
15	Relief Valve	1	A1171UK	0LWV56XUK9219	Steel			
16	O'Ring	1		BS 113	Neoprene			
17	O'Ring	1		As Req'd				
18	Flange	1		As Req'd				

Field Checklist

What to look for when

1. No Oil is delivered
 - Suction lift too high for vapour pressures of liquid pumped
 - While Tuthill Pumps will develop as high as 27 inches of vacuum, it is wise to reduce the vacuum to a minimum
 - Bad leaks in suction line or port passages can be detected by submerging pressure line from discharge side of pump into a pail of oil where the air will be seen in the form of bubbles
 - Wrong direction of shaft rotation (In "R" models, check position of cover boss)
 - Pump shaft not rotating (Check coupling or drive)
 - Relief valve setting too low (Discharging fluid through by-pass port)
2. Capacity is too Low
 - Suction lift too high or air leaks in suction line
 - Suction line too small (Can be detected by installing a vacuum gauge directly at the pump suction)
 - Pump speed too slow, filter is too small, or filter is obstructed
 - Suction pipe or port not immersed in the liquid deep enough
 - Piping improperly installed, permitting air pocket to form in pump
 - Increased clearance or wear in the pump will sometimes cause the pump to deliver an insufficient supply of liquid
 - A folded gasket or some dirt not only will frequently exaggerate the original trouble but will also be the cause of leakage

The maximum vacuum at the pump suction should never exceed 15 inches of mercury. It is necessary to keep below 15 inches not because of the inability of the pump to handle a higher vacuum, but primarily because of the vaporization that is liable to take place at a higher vacuum. Vaporization caused by higher vacuums will generally result in capacity drop-off.

3. Pump Works Spasmodically

- Leaky suction lines
- Suction lift too high
- Air or vapour in liquid
- Coupling slipping on pump shaft.

4. Pump Wastes Power

- Pressure too high
- Liquid more viscous than desired
- Suction or discharge lines obstructed
- Mechanical defects (End thrust on pump shaft)
- Drive shaft and pump shaft misaligned. The pump may be binding due to insufficient end clearance
- Pump shaft bent
- Misalignment within pump due to bad piping or poor installation, causing strains or distortion

Note: Tuthill pumps are not designed to take end thrust toward the pump cover and care must be taken to prevent thrust in this direction.

5. Pump is Noisy

- Machine or part of it is acting as a sounding board
- Misalignment or bad design of coupling
- Coupling set too close to pump
- Vibration of pump because of bent shaft or worn parts
- Air leaks on suction side of pump
- Suction lift too high, causing vaporization.

6. Pump Leaks

- Cover bolts need tightening, or cover gasket is defective
- Seal is defective or worn

Material Returns

If it becomes necessary to return a pump to the factory, a Return Goods Authorization (RGA) must be obtained from either your local Authorized Distributor or our plant. No RGA can be issued until a completed Material Safety Data Sheet (MSDS) has been forwarded to our plant and return of the pump approved.

- Tuthill pumps are precision built and must be handled with care
- Pumps must be drained of all fluid and the ports plugged to prevent foreign material from getting into the pump
- Pumps must be packaged securely to prevent damage while in transit

Tuthill Pump Group

12500 S. Pulaski Road, Alsip, IL 60803

www.tuthillpump.com

Excellence at work. Excellence in life.